


Designer I ^{USB}
EXCLUSIVE SENSOR SYSTEM



Features & Benefits

DESIGNER I USB GENERAL FEATURES

EXCLUSIVE SENSOR SYSTEM

EXCLUSIVE SENSOR FOOT LIFT

Presser foot lowers and raises automatically for every sewing technique. Four positions: down, pivot, up and extra lift. Your hands are free to guide fabric.

EXCLUSIVE SENSOR FOOT PIVOT

Stop with needle down, foot senses thickness of fabric and raises to float position for instant pivoting, easy appliqué and quilting.

EXCLUSIVE SENSOR FOOT PRESSURE

Automatically adjusts for any fabric thickness as you sew for perfect even feeding.

EXCLUSIVE SEWING ADVISOR® FEATURE

Touch the type of fabric and the sewing technique; instantly the best stitch, stitch width and stitch length, thread tension, sewing speed and Sensor Foot Pressure are set. See the stitch, best presser foot and best needle for the selected fabric and technique. Override anytime for specialty techniques.

COLOR TOUCH SCREEN

Everything is right at your fingertips. Preview embroideries in color before sewing.

THREE EMBROIDERY HOOPS INCLUDED

Make designs in three different embroidery hoops. Embroider designs in the Standard Hoop 4" x 4" (100 x 100 mm), Large Hoop 9.6" x 6" (240 x 150 mm), or the Mega Hoop 14.2" x 6" (360 x 150 mm) without repositioning.

HUSQVARNA VIKING USB EMBROIDERY STICK

Save your designs on a special Husqvarna Viking USB Embroidery Stick included with Designer I USB and save up to twelve floppy disks of designs! Transfer your designs from your PC onto your Husqvarna Viking USB Embroidery Stick using the 3D Disk Manager software included.

BUILT IN COLOR CUSTOMIZING

Combine and arrange designs and lettering right on the Color Touch Screen. Save designs on the Husqvarna Viking USB Embroidery Stick for the future.

EXCLUSIVE SELECTIVE THREAD CUTTER

One touch instantly cuts the top and bobbin thread, pulls the top thread to the underside of your fabric and lifts the presser foot. Automatically cuts top thread only for embroidery color changes. Automatically cuts the top and bobbin thread for embroidery, buttonholes, etc. when finish sewing. Program Selective

Thread Cutter to cut automatically at end of a stitch program. Touch the Selective Thread Cutter while sewing or program to automatically trim after you've finished a programmed sequence.

SEE BEFORE YOU SEW

Stitches appear on the Color Touch Screen in the direction they will sew. Any alterations you make appear instantly and presser foot is recommended.

QUICKFONT PLUS INCLUDED

Unlimited embroidery fonts. Create an embroidery font from any true-type font in your computer.

MADE IN SWEDEN

Husqvarna Viking has engineered and manufactured superior quality sewing machines and developed cutting edge technology for over 130 years.

FIX FUNCTION

Touch FIX to stop and lock any stitch instantly with tiny forward and backward stitches. Program FIX for instant tie-off in a stitch program.

STOP FUNCTION

Touch STOP to finish stitch or stitch program and tie off automatically. Perfect for single stitch tying of quilts and quilted projects.

INSTANT AND PERMANENT REVERSE

Touch REVERSE to sew any stitch backward for lockstitch and tie off. Touch REVERSE twice for permanent reverse.

SPEED ADJUSTMENT

Touch SPEED to adjust to five sewing speeds according to your sewing project and skill level. Perfect for teaching sewing.

SEW WITHOUT FOOT CONTROL

Touch START/STOP to begin and to stop sewing and embroidering. Perfect for long rows of stitching at a steady speed so you can concentrate on your project. Ideal for sewers with physical limitations.

NEEDLE STOP UP/DOWN

Set needle stop up or down for pivoting, appliqué and more. Tap foot control or touch button to move needle up or down at any time.

STITCH RE-START

Touch Stitch Re-start to begin sewing at the start of any stitch or stitch program. All stitch adjustments will be retained.

TRULY AUTOMATIC SELF ADJUSTING TENSION

Best tension for all sewing and embroidery set automatically. Override automatic tension easily for specialty techniques.

TWO BUILT-IN SPOOL PINS

Horizontal and vertical thread delivery for twin needle sewing, specialty sewing

and topstitching techniques. Wind bobbin easily while sewing or embroidering.

TWIN NEEDLE SAFETY

Enter twin needle width to set maximum stitch width for any stitch.

EASY THREADING & AUTOMATIC NEEDLE THREADER

QUICK WIND BOBBIN

Wind bobbin from needle; no need to unthread and rethread.

JAM PROOF ROTARY HOOK

Threads float around bobbin area for jam free sewing.

PERMANENTLY LUBRICATED

No oiling means no stains on fabric.

TOP AND BOBBIN THREAD SENSOR

Designer I USB stops sewing and alerts you when thread runs out or breaks.

SNAP OFF AND ON PRESSER FEET

Change presser feet quickly and easily.

EXCLUSIVE ONE STEP BUTTONHOLE SENSOR FOOT & PBB

One Step Buttonhole Sensor Foot sews perfect buttonholes, repeatedly. Perfectly Balanced Buttonholes (PBB) with the exclusive One-Step Buttonhole Sensor Foot sews both columns in the same direction for balanced, professional buttonholes.

20 SPECIALTY STITCH MENUS FEATURE 700+ STITCHES

Every possible stitch you desire at your fingertips for endless creative opportunities. One touch stitch selection. Program from menu to menu with a touch.

STYLUS

Use your stylus for easier stitch selection on your Color Touch Screen.

PICTOGRAM EMBROIDERY

Thirty-five satin element stitches to program in combination for creating original decorative stitches and Pictogram embroidery.

ELONGATION

Increase or decrease the size of decorative satin stitches and Pictogram elements with elongation. The density of the stitch remains the same.

OMNIMOTION STITCHES AND SCALLOPS

Side motion feeding creates up to 36.5 mm wide decorative stitches and scallops. Large Omnimotion scallops and small, dainty scallops to finish the edges of all your projects.

FOUR-WAY STITCHES

Fifteen different stitches to sew in four directions for patching and mending tears.

EIGHT-WAY STITCHES

Straight stitch and reinforced straight stitch that can be sewn in 8 directions without turning the fabric. Program together with other stitches to achieve large decorative borders and embellishments.

MY STITCHES MENU

Save your favorite stitches or stitch programs in your personal menu to sew them again whenever you wish.

SPECIALTY TECHNIQUES

Select Menu V for specialty techniques such as free hand stippling, tacking etc.

EASY PROGRAMMING

See the stitch and/or lettering combinations horizontally as you put them into program. Program FIX and the selective thread cutter for instant tie-off at the end of the sequence. Touch repeat to see them in the direction they will sew. Save stitch combinations in My Stitches.

PERMANENT MEMORIES

15 Permanent memories, each holds 62 stitches for stitch and/or lettering programs, maximum up to 930 stitches total.

25 NEEDLE POSITIONS

Set exact needle position for topstitching, sewing zippers, quilting, specialty techniques, and accessory presser feet. See the needle position move on the Color Touch Screen.

ADJUSTABLE STITCH WIDTH AND STITCH LENGTH

Adjust stitch width from 0 - 6 mm and for Omnimotion stitches up to 36.5 mm. Adjust stitch length from 0 - 6 mm for specialty sewing.

MIRROR IMAGE

Flip stitches and/or stitch programs side to side and/or end to end for unlimited creative combinations.

HELP

HELP tells you everything you need to know to sew. Recommends needle type and size, stabilizer, buttonhole tips and more.

SCREEN SAVER OPTION

ERGONOMICALLY DESIGNED: COLOR TOUCH SCREEN

Up-front convenient threading, bobbin winding, bobbin placement. All settings at your fingertips with ergonomically-placed function buttons and Color Touch Screen. One piece aluminum casting is lightweight yet strong, long lasting and prevents vibration. Ergonomically designed foot control with self winding cord.

LARGE WORK SPACE

Large work space inside sewing arm gives ample room for quilting and extra large projects. Extra long free arm makes sewing sleeves and pant legs easy.

BUILT-IN RULER

Built-in ruler lets you measure anything. Convert from inches to centimeters in an instant.

SLIDE ON ACCESSORY TRAY

Slide on Accessory Tray locks in place and stores bobbins, accessory feet, needles and more, right at your finger-tips.

CARRYING CASE

Attractive light-weight Carrying Case protects your Designer I USB and accessories for storage and/or transport.

DUAL LIGHTS

Dual lights give excellent illumination over work area and just above needle.

DESIGNER I USB EMBROIDERY FEATURES

SLIDE-ON EMBROIDERY UNIT

Instant embroidery ability with large surface.

AUTOMATIC FEED TEETH DROP

Feed teeth lower and raise automatically for sewing, embroidery and special techniques.

SENSOR FOOT PRESSURE

Embroidery foot glides over different thickness of fabric and previous embroidery stitches.

THREE EMBROIDERY HOOPS AND PLACEMENT TEMPLATES

Standard Hoop for designs up to 4" x 4" (100 x 100 mm). Large Hoop for designs up to 9 1/2" x 6" (240 x 150 mm). Mega Hoop for designs up to 14 1/4" x 6" (360 x 150 mm). Optional hoops available include Mini Spring Hoop, Round Spring Hoop, Mid-Size Hoop, Do All Quilter's Hoop, and Endless Embroidery Hoop.

DESIGNS INCLUDED

The included Husqvarna Viking USB Embroidery Stick comes loaded with beautiful embroideries for the standard hoop size up to the Mega Hoop. It features the Designer sampler collection and Embroidery Collection 114 "Classic Fashion". Three fonts are also included; Clarendon, Palace Script and Calligraphia for monogramming and numbering. The Embroidery Booklet pictures designs in actual size and gives thread colors by number.

BASTE IN HOOP

Use FIX to baste fabric to stabilizer around the embroidery area and to avoid hooping specialty fabrics.

MOVE DESIGN IN HOOP

Use your placement buttons for exact positioning of designs.

ENLARGE AND REDUCE SIZE

Scale design quickly with icons directly on the Color Touch Screen.

PREVIEW DESIGN, COLORS AND PLACEMENT

Touch check size icon repeatedly to see the size of your design in the embroidery hoop and where it will sew.

COLOR STOPS

Designer I USB stops sewing, beeps to alert you and cuts the top thread automatically for a new thread color.

STEP-THROUGH DESIGNS

Step through designs by color or by stitch to move to any part of a design or to sew only parts of a design. Cursor marks position of needle precisely in the design to track the progress and accurately step through embroidery.

EASY ONE COLOR EMBROIDERY

Simply touch the STOP button to cancel color stops and sew one color or tone-on-tone embroideries.

DECORATIVE STITCHES IN THE HOOP

Sew decorative stitches in the embroidery hoop for stitch borders, frames, outlines and more.

PLACEMENT TEMPLATE

Placement template is included. Trace the designs onto the placement templates and mark design placement lines on the fabric.

EMBROIDERY SEWING SPEED

Computer-controlled speed for best stitch quality. Adjust manually when using specialty threads.

OPTIONAL HUSQVARNA VIKING EMBROIDERY COLLECTION ON CD

Highest quality embroidery designs from top name artists and designers.

HUSQVARNA VIKING EMBROIDERY WEB SHOP

Thousands of designs to order at your local Husqvarna Viking Dealer or download from the Internet any time, day or night.

OPTIONAL HUSQVARNA VIKING 3D PROFESSIONAL EMBROIDERY SOFTWARE

Choose from the most advanced embroidery software for the home sewer. Purchase program by program or the complete Husqvarna Viking 3D Professional System. Husqvarna Viking provides programs that allow sewers the option to move at their own pace as their creativity flourishes.